


SR 507

EN

Spare parts / Accessories



No.	Description	Ordering No.
1.	Connection adapter	R03-0602
2.	SR 348 Control valve	R03-0601
2a.	Safety coupling female 1/4"	R03-0352
3.	Belt	R03-1510
	Belt PVC	T01-3008
4.	SR 358 Plastic hose 5/10/15/20/25/30 m	H03-30XX
	SR 359 Rubber hose 5/10/15/20/25/30 m	H03-31XX
	SR 360 Spiral hose 2/4/6/8 m	H03-34XX
5.	Flow meter	R03-0346
6.	SR 5226 Cleaning wipe, box of 50	H09-0401