


# SR 500

EN

## Spare parts / Accessories



<b>No.</b>	<b>Description</b>	<b>Ordering No.</b>
1.	Fan unit SR 500, bare	R06-0110
2.	Gasket	R06-0107
3.	Combined filter A1BE2K1-Hg-P3 R, SR 599	H02-7312
4.	Gas filter A1BE2K1, SR 597	H02-7212
	Gas filter ABE1, SR 515	H02-7112
	Gas filter A2, SR 518	H02-7012
5.	Particle filter P3 R, SR 510	H02-1312
6.	Filter adapter SR 511	R06-0105
7.	Particle filter P3 R, SR 710	H02-1512
8.	Pre-filter SR 221	H02-0312
9.	Steel net disc SR 336	T01-2001
10.	Pre-filter holder	R01-0605
11.	Pre-filter holder SR 512	R06-0106
12.	Asbestos kit SR 509	T06-0105
13.	STD Standard battery, 2,25 Ah	R06-0108
	HD Battery, 3,5 Ah	T06-0101
14.	Battery charger SR 513	R06-0103
15.	Charger stand SR 506	T06-0108
	Charger and chargerstand SR 516	T06-0111
16.	Belt PES SR 508	R06-0101
	Rubber belt SR 504	T06-0104
	Belt PVC	T06-0124
17.	Leather belt SR 503	T06-0103
	Leather belt SR 503, large	T06-0107
18.	HD belt SR 553, standard	T06-0119
	HD belt SR 553, large	T06-0120
19.	Harness SR 552	T06-0116
20.	Flow meter SR 356	R03-0346
21.	Storage bag SR 505	T06-0102
22.	Splash cover SR 514	T06-0114
23.	Plug kit	R06-0703
24.	Cleaning wipes 50/box	H09-0401